Dell Inspiron 14z N114z Battery Replacement

This is a step by step guide on how to remove the battery from the laptop.


Written By: Duggan Young



INTRODUCTION

The battery is the least difficult part of this laptop to remove and replace, and this guide will serve as the first step in all subsequent guides.

Step 1 — Battery





- Using your thumbs, push out on both side tabs simultaneously. You should hear a soft click and see the battery slightly pop out.
- Grab and lift the battery off from the underside of the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 02:44:02 AM.